



Frameless Whiteboard

Instruction leaflet


<i>FWB4560</i>	45 x 60 cm	<i>FWB100100</i>	100 x 100 cm
<i>FWB6090</i>	60 x 90 cm	<i>FWB100150</i>	100 x 150 cm
<i>FWB80110</i>	80 x 110 cm	<i>FWB100200</i>	100 x 200 cm
<i>FWB90120</i>	90 x 120 cm		




±10 min



x 1










Vertical




Horizontal


Parts and tools




STEP 1



STEP 2



STEP 3



*Dry wipe surface. Never clean it with alcohol or abrasive products as the surface may be damaged. Please use a wet cloth to erase the surface.
This product do not need any especial attention in the use or basic knowledge of its parts for it use is free of any security advertise.*